

User Guide

Hello, thank you for purchasing this music box.

Please note in advance: No tracks are pre loaded in this unit at the factory due to copyright considerations. The advantage of this design is that you may freely assign exclusive music to each vinyl style record, and songs can be replaced anytime later. Please follow the operating steps below to import your own MP3 audio files into the music box for use.

Video Tutorial



Scan the QR code with your phone's camera or Google Lens to watch the video tutorial.



1. Connection



A. Use the included Type C data cable to connect the main player unit to a desktop or laptop computer.

Note: An adapter is required for Mac devices.

B. Once connected, the device will appear as an external storage drive containing nine numbered folders from 01-09 (folder names must not be modified). It is natively recognized by both Windows and Mac systems; no additional drivers or dedicated software are required.

C. There is also a folder named Tutorial, deletable once learned, which stores product operation tutorial videos. We recommend reading the user guide thoroughly first, then referring to the videos for hands on operation. You may delete this folder once you are familiar with the product functions.

2. Adding & Replacing Music



Important Note:

For Mac users, when adding or replacing tracks and deleting existing files, make sure to use the shortcut Option + Command + Delete. This same method must also be used to remove old files for future music replacements.

Drag and drop MP3 format files directly into the corresponding numbered folders. **Only MP3 format is supported**; formats including WAV, FLAC, M4A and WEBNN are not compatible.

Do not store unrelated files such as album covers or TXT documents in the folders.

3. Safe Ejection

Always safely eject the storage device before disconnecting it.

Windows: Right click the corresponding drive and select Eject. **Mac:** Drag the drive icon to the Trash to complete ejection.

4. Attach the Numbered NFC Stickers




The kit comes with nine numbered NFC sticker chips (01-09).

Affix each sticker to the back of the record. Make sure the number on the sticker corresponds exactly to the number of the folder where your music files are stored.

For example: If you attach the No.01 sticker to a record, the record will read and play the MP3 audio files inside Folder 01.

5. Play Your Music



After disconnecting the data cable, press and hold the power button to power on the device. Place the record on the induction area at the center of the unit, and the device will automatically play the corresponding track. Please refer to the illustration for volume adjustment instructions.